

Owners Manual

D7



BMW Marine Engines

This copy of the BMW D7 Owners Manual has been re-created using images computer scanned from a manual rather than original artwork. It has also been re-formatted in "portrait" style to display and/or print better on computer systems.



This manual was written on your behalf in an effort to help you enjoy your new BMW Marine Engine to the maximum. No marine engine, be it the best in the world, will perform at it's best during a long life, without proper care and maintenance.

Please read this manual carefully before you set out on the first trip with your new BMW Marine Engine.

⚠ For the practical boat owner, some maintenance procedures are described in this manual. Next to some jobs, you will find this marking which indicates that the work will require special tools as well as certain special knowledge. It is, therefore, recommended that your authorized BMW Marine Dealer complete these operations.


INDEX

ENGINE DESCRIPTION	4
INSTRUMENTS AND CONTROLS	6
STARTING AND OPERATING	7
SERVICE & MAINTENANCE	12
FUEL SYSTEM	13
LUBRICATION SYSTEM	16
COOLING SYSTEM	17
VALVE SYSTEM	19
ELECTRICAL SYSTEM	20
WINTER LAY UP AND RECOMISSION	21

ENGINE DESCRIPTION

The BMW D7 is a single-cylinder, four-stroke, direct-injection diesel engine. The engine is equipped with a raw-water cooling system, fed by an impeller type pump driven by the crankshaft. Electrical starting and charging systems are standard as is an automatic air bleeder device in the fuel system.

Technical Data		
Displacement	280cc	17.0 cu in
Stroke & Bore	67 x 73 mm	2.63 x 2.87 in
Max output at min ⁻¹ (RPM)	4.5 kW / 3600	6 HP / 3600
Max torque at min ⁻¹ (RPM)	11.7 Nm / 3300 1.2 kpm / 3300	8.7 lb ft / 3300
Compression Ratio	19:1	
Weight, dry engine incl. Gearbox	68 kg	150 lb.
Gearbox reduction	2.7	
Maximum engine inclination	15 deg	



Specifications	Engine	Gearbox
Fuel	Diesel Oil DIN 51601 (USA #2)	
Fuel Filter	BMW 13 32 1 329 270	
Lubrication oil Type Capacity – Litre (US gal)	HD-API CC/CD SAE 30 1 litre (0.26 US Gal)	ATF Dexron 0.4 litre (0.1 US Gal)
Air Filter	BMW 13 71 1 329 269	
Injector make	Bosch	
Injection pressure	135 + 8 bar	
Injection pump	Bosch PFE 1 Q 55/19	
Starter motor make	Bosch	
Alternator, charging capacity	14v 350w	
Battery, rec capacity	12v 60 Ah	
Polarity	Negative ground	
Raw-water pump	Johnson	
Gearbox	Hurth HBW 5	


Adjustment Data		
Injection ends	11.5 – 12.5 deg BTDC	
Tappet clearance	0.15 mm .006 in	

Torque	Nm	lb.ft
Injector retainer	10	7.2
Cylinder head bolts	35	25

INSTRUMENTS & CONTROLS

Instruments


The BMW D7 is equipped with an instrument panel as shown:



1. *Starter Switch* – with three positions:
 - "O" – the circuit is switched off, and the key can be removed
 - "II" – the current is switched on and the alternator charging control lamp lights
 - "S" – the started is engaged. When the engine fires the key should be released and will automatically return to position "II"
2. *Alternator Charging Control Lamp* – is normally out when the engine is running above idle speed
3. *Engine Temperature Control Light* – should be out at all times except if engine temperature exceeds 70°C or 160°F. In such cases the engine must be stopped at once or *severe damage may occur*. Find the trouble before the engine is restarted.
4. The panel also has a reserve lamp marked "OIL", which is not connected

Controls

Throttle and gearshift are both operated by single-lever remote control, which works as shown:



N	=	Neutral
F1	=	Forward gear engaged
F2	=	The RPM increases
B1	=	Reverse gear engaged
B2	=	RPM increases


To disengage the gearshift mechanism, push the knob – 2 – fully in, for instance when starting the engine.

Aloha Owners Association note – the control fitted to Aloha 27s is not always the same as this, and in some cases you pull the knob OUT to disengage.

STARTING AND OPERATING

The Decompression Valve

The automatic decompression valve makes starting easier, particularly manual starting. The valve is operated by a twist grip. In the “0” position the valve is closed, while in the “1” sector it is open, but the automatic control device is not engaged. In the “2” sector it is open and the automatic control device is engaged.




Turning the grip further – always clock-wise – will engage the automatic control. When the engine is cranked, the valve will automatically return notch by notch to the “0” position. This takes four full turns of the crank handle and the speed gained thereby should make the engine fire at the first following compression stroke.

Use of the decompression valve is also helpful when the battery is too low for sufficient cranking speed.

NOTE – never use the decompression valve to stop the engine


Cold Starting Device

Situated next to the injection pump (on the starboard side just forward of the dipstick). When starting a cold engine, the knob is pulled out fully and the RPM control (throttle) in cockpit pushed to the “full” position, with the gear disengaged.




Cold Weather Starting Aid

A cold start primer is located on top of the cylinder head. Fill with diesel or lubricating oil with the cover removed and press the cover fully down prior to starting.




Engine Shut-Off Control

Pull the handle and hold it in this position until the engine has completely stopped.



A running-in period of approximately 10 hours when the maximum RPM should not exceed 3000 min^{-1} will prolong engine and gearbox life. After these 10 hours, the engine should be checked by a BMW Marine Dealer in accordance with the instructions in the service section.

Always check the engine oil level, prior to the first starting of the day.



Air Bleeding

The BMW D7 fuel system incorporates a fully automatic air-bleed device.

Prior to starting up after a long rest period or when the fuel system has been worked on, operate the primer pump some 30–50 strokes, which will save the battery and starter. (For location of primer pump see diagrams on pages 13 & 15)

Starting A Cold Engine

- Check that the gear-shift is in neutral
- Set the throttle at the “full” position
- Turn the starter switch key to the “II” position and check that the alternator charging control lamp comes on
- Turn the key to the “S” position which will engage the starter motor. When the engine fires evenly, release the starter switch key
- Set the throttle at normal idling

Important – see NOTES on next page.

NOTE

If outside temperature is extremely low, the primer device on top of the cylinder head (see diagram on page 8) should be filled with diesel or lubricating oil and the plug fully pressed down to inject the oil into the intake manifold.

NOTE

Since a diesel engine is dependent on a certain compression pressure = heat to ignite the fuel, one may have to operate the starter for longer periods than is the case with a gasoline engine. Under no circumstances should the starter be engaged for more than thirty seconds at a time.


A battery too low for sufficient cranking speed will doom the starting from the beginning and the battery will drain very rapidly. In such a case, try the decompression valve, or crank the engine manually.

Starting A Warm Engine

- Check that the gear-shift is in neutral
- Set the throttle at the “full” position
- Turn the starter switch key to the “I” position and check that the alternator charging control lamp comes on
- Turn the key to the “S” position which will engage the starter motor.
- Release the key as soon as the engine fires
- Decrease the RPM to normal idling
- Check that the alternator charging control lamp is out and the gear-shift is re-engaged

Manual Starting

- Prepare the starting according to the instructions for a cold engine on page 9
- Insert the crank handle and make sure it is properly engaged
- Turn the decompression valve twist grip almost 180° clockwise
- Hold the crank handle as shown i.e. with fingers and thumb on the same side of the handle thus avoiding spraining the hands should the engine rotate backwards
- Crank the engine as rapidly and vigorously as possible. After four crank handle revolutions, the decompression valve will close and the engine will fire normally
- Remove the crank handle and decrease RPM to normal idling



Aloha Owners Association note – owners of some Aloha 27s advise that due to the close proximity of the bulkhead there may be insufficient clearance to allow insertion of the crank handle for manual starting

Stopping the engine

- Set the control in neutral and allow the engine a few minutes idling in order to even out any thermal stresses
- Pull the shut-off handle fully until the engine has completely stopped

NOTE – never use the decompression valve to stop the engine

SERVICE AND MAINTENANCE


Periodical service and maintenance procedures are listed below.

The  marking indicates that the procedure in question requires special tools and certain knowledge and should be left to your authorized BMW Marine Dealer.

Jobs to be done	Engine hours	Page
Oil level check	Daily	16
Oil change, engine	50 or once yearly First change after 10 hours	16
Oil change, gearbox	150 or once yearly	16
Fuel primary filter, draining	Every two weeks	13
Fuel primary filter, cartridge replacement	100 or once yearly	13
Fuel screen cleaning (inside the feed pump)	100 or once yearly	13
Air filter, replacement	100 or once yearly	15
 Tappet clearance, checking/adjusting	100 or once yearly	19
 Injector, cleaning	When necessary	14
Sacrificing anodes, checking/replacing	Replaced once yearly	18
Impeller, raw water pump checking/replacing	100 or once yearly	17
 Decompression valve, adjusting	100 or whenever tappet clearance is altered	19


FUEL SYSTEM

Fuel flow circuit




Number markings refer to corresponding paragraph

1. *The fuel tank* – consult the tank manufacturers or boat builders instructions for proper draining, cleaning and other maintenance procedures.
NOTE – diesel fuel should not be left in the tank during the lay-up period due to rust, sludge or wax deposits forming.




2. *The fuel pump* – (located on the port side of the engine) is of the diaphragm type, operated by the camshaft. Underneath the pump housing cover there is a screen type pump which needs cleaning at regular intervals. The filter sealing ring as well as the gasket at the cover centre should be renewed whenever the parts are dismantled. Apart from this, the pump needs no maintenance and is replaced as a complete unit if there are any doubts about its functioning.
3. *The primary fuel filter* – with water trap. Water and dirt deposits are drained by removing the knurled plud with a suitable container underneath to catch the spill. The spin-on type filter cartridge (Type BMW 13 321 329 270) is replaced at regular intervals – see maintenance schedule on page 12.




NOTE – the filter cartridge cannot be cleaned and used again.

4. *The injection pump* – of Bosch make, must not be dealt or tampered with by anyone other than an authorised BMW Marine Engine or Bosch diesel dealer. Should the pump need to be removed, it is very important that all openings, fuel line connectors, etc are properly sealed to prevent contamination.



5. *The injector* – of Bosch manufacture, will normally need no maintenance except for cleaning of the area next to the atomizer. The injector must not be dismantled, since the set injection pressure then could be altered inadvertently.




WARNING – when the injector is tested outside the cylinder, the jet must not be directed towards unprotected skin, eyes, etc as it is powerful enough to penetrate the skin, causing nasty wounds and possible infection.

When installing the injector, make sure that the cylinder head seal is clean and the nuts evenly tightened to 1.0 kpm (7.2 lb.ft.)


6. *The return pipes* – direct surplus fuel to the tank and evacuate any air locks.

NOTE – whenever the fuel system has been serviced, bleeding it by operating the primer pump some 30 – 50 strokes is worthwhile. Any air locks trapped in the system will otherwise cause trouble or make starting impossible.



NOTE – handling the fuel system requires total cleanliness. The injection pump and injector tolerances are very fine and any fragment of dirt or the tiniest amount of water could ruin the injector operation.


Air filter replacement – is easily carried out by undoing the filter housing clasps. The filter paper element is discarded and cannot be used again. Clean out the filter housing and install a new element. (Type BMW 13 321 329 269)



LUBRICATION SYSTEM


The BMW D7 is equipped with a simple and reliable splash lubrication system.

Oil level check – is done daily with aid of the dipstick




Engine oil change – normally every 50 hours. A brand new engine, however, will require it's first oil change after ten or fifteen hours running. Pump out the oil via the dipstick opening while the engine is warm. Refill via the crankcase filler plug.

Gearbox oil change – is carried out at 150 hour intervals and when the gearbox is still warm. Remove the drain plug – 1 – and the filling opening plug – 2 -. Allow the oil enough time to drain completely. Check that the drain plug seal is undamaged prior to re-installation. Top up the gearbox slowly with 0.4 litres (0.1 US gal) ATF Dexron oil. Leave the filling opening open for some minutes until any possible air locks have escaped. Check the plug seal and install the plug.




COOLING SYSTEM

The engine has a raw-water direct cooling system fed by an impeller type pump located on the front of the engine and driven by the crankshaft. The water is circulated through the cylinder block and cylinder head jackets and finally discarded via a thermostat controlled outlet into the exhaust manifold.




Pump impeller change – is possible when the pump housing front cover is removed. Pry the impeller off its shaft using two screwdrivers. Lubricate the shaft and the impeller vanes with a few drops of oil prior to installation. Bend the vanes opposite to the direction of rotation in order to avoid distortion. Renew the pump housing gasket and install the cover.



NOTE – the impeller should be removed prior to lay-up – see instructions on page 21

The engine temperature warning light sensor – 1 – and self-sacrificing anodes – 2 – are situated next to the thermostat housing – 3 – . The anodes resist internal corrosion in the cooling system.



The self-sacrificing anodes – are checked regularly and replaced if more than 50% has been eaten away by corrosion. Undo the anodes – 2 – and replace them with new ones, including new gaskets.

The thermostat – will open at 55°C (130°F). It is accessible when the exhaust manifold is removed – 3 – . Check the thermostat by submerging it in hot water. Always use a new gasket when re-installing the manifold.


Draining the cooling system – is done by removing the lower sacrificial anode.

VALVE SYSTEM

The overhead valves are operated by the camshaft via pushrods and rocker arms.

Tappet Clearance

- to be checked and adjusted while the engine is cold
- set the decompression valve twist grip in the “0” position
- remove the rocker arm cover, attached with two studs and nuts
- crank the engine until the compression resistance is clearly noticeable
- use a feeler gauge to check the clearance between rocker arm and valve. Correct clearance = 0.15mm (.006 in)
- adjust if necessary by loosening the adjustment screw lock nut at the rocker arm push-rod end – 1 –
- turn the adjustment screw either way until the correct clearance is achieved
- hold the screw in position while the lock nut is tightened
- check the clearance once more
- repeat the same procedure at the remaining valve
- re-install the cover with a new gasket




The Decompression Valve

- is checked and adjusted when the valve mechanism has been worked on or if the proper setting has been altered for other reasons affecting the correct functioning of the valve
- remove the rocker arm cover
- check and adjust the tappet clearance
- turn the decompression handle to position “1”
- undo the decompression valve adjusting screw locknut – 2 –
- turn the adjustment screw counter-clockwise until the rocker arm clearance is clearly noticeable
- turn the adjustment screw clockwise until the rocker arm is just in touch with the valve and then another half turn – 180° – in the same direction
- hold the screw in position while the locknut is tightened
- install the rocker arm cover and a new gasket
- set the decompression valve twist grip in “0” position

ELECTRICAL SYSTEM

The BMW D7 is equipped with a 12 volt electrical system, consisting of a starter motor operating on the flywheel ring gear and an internal alternator with static charging coils inside the flywheel. The maximum charging capacity is 14 V 350 W at 2000 RPM.


A panel with rectifier, regulator and fuses completes the installation.



The alternator charging control light in the instrument panel will light up when the starter switch key is turned to "II" position, but should go out when the engine runs, indicating that everything is in order. If not, consult your BMW Marine Dealer as in case of any starter motor malfunctioning.

Apart from replacing any burned fuses - make sure that the correct type of replacement is used - the electrical system should need no maintenance. Check, however, that all visible connections are clean and tightened.

Wiring Diagram



1 Charge Control Lamp
2 Water Temp Lamp
3 Spare (Oil) Lamp
4 Keyswitch
5 Plug – 9 Pin

6 Water Temp Switch
7 Regulator
8 Impulse Transmitter
9 Plug – 1 Pin
10 Plug – 4 Pin

11 Flywheel Generator
12 Fuse box 25A
13 Starter
14 Battery

BL = Blue
BR = Brown
GN = Green
RT = Red
SW = Black
WS = White

WINTER LAY-UP AND RECOMISSION

Prior to winter lay-up or any long periods of rest the engine should be prepared for storage, mainly to fend off corrosion. Either leave this job to the authorized BMW Marine Dealer or do it yourself according to the following instructions:

Before the boat is taken out of the water

- warm up the engine and remove the oil, see page 16
- use *preservation oil* level with the dipstick lower marking
- drain the gearbox oil and refill with ATE Dexron oil

NOTE - before the engine is recommissioned, the preservation oil must be removed and replaced by recommended engine oil. Some kind of marking is useful as a reminder.

- Mix 2 litres (0.5 US gal.) diesel fuel with 1 litre (0.25 US gal.) preservation oil in a suitable container. Connect a hose to the ordinary fuel tank line or directly to the primary filter inlet while the other end is inserted into the container
- Start the engine and let it run for approximately 15 minutes

On dry land

- Drain the engine cooling system, but without removing the cooling water pump impeller
- Shut off the raw water inlet and disconnect the raw water pipe at the pump
- Mix approximately 12 litres of fresh water with 1.2 litres of emulsifying preservation oil in a container. Always mix the oil with water, not the other way round, and stir vigorously
- Connect a hose to the raw-water pump and put the open end in the container
- Start the engine and let it idle until the oil/water mixture is nearly gone. Stop the engine. Make sure that no liquid remains in the system since it has no anti-freeze qualities
- Remove the injector and pour approximately 1 teaspoonful of oil into the cylinder. Crank the engine a couple of turns and re-install the injector.
- Give the engine and gearbox a good cleaning and a coat of oil to prevent rust
- Lubricate control cables and linkage.

Recomission before launching

- Remove all preservation oil in the engine and replace with recommended oil
- Install the raw-water pump impeller
- Remove the injector and crank the engine a few turns to get rid of surplus oil in the combustion chamber
- Change fuel filters
- Refuel with fresh diesel fuel. Fuel left in the tank during winter storage should never be used. Check lines and connectors
- Start the engine after launching - **do not forget** to reopen the raw-water inlet. Warm up the engine and check that there are no leaks in fuel or cooling systems.